













Aluminum Wheel Cleaner & Aluminum Wheel Coating

Operating Procedures

Aluminum Wheel Cleaner Work Procedure

	<p>① Do before car wash. Things to prepare -Cleaner -High Pressure Gun</p>
	<p>② Spray the cleaner. -100ml in 1bottle -Price- 245円 Place a large amount of spray on the back side from the front side.</p>
	<p>③ Spray the cleaner and after a while it turns purple when reacted with iron.</p>
	<p>④ High Pressure Gun Available! In particular, insert a high pressure gun on the back and wash with a person with strong pressure. ★Europe cars are easy to do!</p>
	<p>⑤ Please wash thoroughly! Insert the high pressure gun to the inside of the wheel and wash.</p>
	<p>⑥ After cleaning ,the high pressure gun,drain the tires and wheels with an air gun.</p>

Aluminum Wheel Coating Work Procedure

	<p>⑦ After draining the tires and wheels, apply wheel coating. KOTAC-G REVOII</p>
	<p>⑧ Spray appropriate amount of KOTAC-G REVOII on sponge.</p>
	<p>⑨ Apply the coating agent to the wheels. If less, repeat step ⑧.</p>
	<p>⑩ Small details apply carefully. After application, dry for 3to5 minutes.</p>
	<p>⑪ Carefully Dry!</p>
	<p>⑫ Complete Wheel Coating!</p>